

### **Genstart af vægsæt som følgende:**

1. Fjern oplader fra el tilslutning.
2. Vent i 10 sekunder.
3. Tilslut oplader til el tilslutning og vent i 15 sek.
4. Pres knappen (IN) inde ca. 10 sek.
5. Slip knappen.
6. Fjern oplader fra el tilslutning i ca. 10 sek. (Rød lampe skulle nu blinke).
7. Tilslut oplader til el tilslutning, nu klar.

Hvis de der ikke forekommer flash blink mellem Step 6 og 7, start forfra fra punkt 1.

### **Reset for wallset is performed as follows:**

1. Remove charger from wall socket.
2. Wait for 10 seconds.
3. Attach charger back to wall socket and wait for 15 seconds.
4. Press the left button (IN) for about 10 second (keep it down for that time).
5. Release the button.
6. Remove charger from wall socket for 10 seconds (led lights should now blink).
7. Attach charger to wall socket, now ready.

If you did not notice led light blinking between step 6 and 7, the reset is not successfully. Try again starting from step 1.

### **Genstart af håndsæt:**

1. Tilslut håndsæt til el tilslutning via oplader, og lad opladeren lade i 5 minutter (grøn lampe begynder at blinke eller lyse konstant).
2. Medens håndsættet stadig bliver opladet, trykkes scannerknappen indtil den røde og grønne lampe begynder at blinke (hvilket sker efter ca. 10 sekunder).
3. Terminalen genstarter, og fortsætter hermed indtil der ikke blinker nogen lamper.
4. Test om håndsættet nu kan læse og overføre informationer til systemet.

### **Reset of handset:**

1. Attach the handset to charger and let device charge for 5 minutes (green light should flash or be switched on).
2. While the handset is in the charger, press the button continuously until red and green lights start to flash (should happen within 10 sec.).
3. The device now restarts, wait until no lights are flashing.
4. Test if device can now read tags.